



### Standard removal of protective lacquers, resins, putties pitch and wax

Bath	Product	Concentration	Temperature	Time
1	<b>deconex OP 192</b>	100%	38-45 °C	3-5 min
2	<b>deconex OP 192</b>	100%	38-45 °C	3-5 min
3	Rinse tap water	-	room temperature	3-5 min
4	<b>deconex OP 164</b>	2%	35-48 °C	3-5 min
5	Rinse tap water	-	room temperature	3-5 min
6	Rinse DI water	-	room temperature	3-5 min
7	Rinse DI water with lift out	-	35 °C	3-5 min
8	Drying	-	70 °C	3-5 min