



pH-neutral cleaning (suitable for all precision optic components)

Bath	Product	Concentration	Temperature	Time
1	deconex OP 164	3%	38-45 °C	3-5 min
2	Rinse tap water	-	room temperature	3-5 min
3	deconex OP 164	1%	38-45 °C	3-5 min
4	Rinse tap water	-	room temperature	3-5 min
5	Rinse DI water	-	room temperature	3-5 min
6	Rinse DI water with lift out	-	35 °C	3-5 min
7	Drying	-	70 °C	3-5 min