



Ready-for-inspection cleaning of prosafe tape

| Bath | Product | Concentration | Temperature | Time |
|------|---|---------------|--------------------------|---------|
| 1 | Deblocking Tap water | - | approx. 60 °C | 3-5 min |
| 2 | deconex OP 141 | 2% | 55-60 °C | 3-5 min |
| 3 | deconex OP 148, deconex OP 149 for mineral glass; deconex OP 141, deconex OP 146 for organic glass | 3-5% | 55-60 °C | 3-5 min |
| 4 | Rinse tap water | - | room temperature | 3-5 min |
| 5 | deconex OP 171, deconex OP 121, deconex OP 141, deconex OP 149 | 1-2% | 55-60 °C | 3-5 min |
| 6 | Rinse tap water | - | room temperature | 3-5 min |
| 7 | Rinse DI water | - | room temperature | 3-5 min |
| 8 | Rinse DI water | - | room temperature - 50 °C | 3-5 min |
| 9 | Drying | - | 70 °C | 3-5 min |